GS2002/GS2002V
GS2101/GS2101V
User Manual

WWW.GADSPOT.COM

CONTENTS

Chapter 1: DVR Features **2**

Chapter 2: Layout **3**

2.1 Front Panel *3*

2.1.1 4-Channel Front Panel 3

2.1.2 8- Channel Front Panel 3

2.2 Rear Panel *4*

2.2.1 Channel Rear Panel 4

2.3 Remote Control *5*

Chapter 3: DVR Installation **6**

3.1 Hard Drive Installation *6*

3.2 Camera and Monitor Connection *7*

3.3 Power Supply connection *7*

Chapter 4: DVR Boot up **8**

4.1 System Initialization *8*

4.2 Main Interface *8*

Chapter 5: DVR Menu **8**

5.1 Main Menu Preview *9*

5.2 Main Menu *9*

5.2.1 Camera setup 10

5.2.2 Record setup 10

5.2.3 Network Set 11

5.2.4 Recording Search 13

5.2.5 Multi player 14

5.2.6 Device Management 16

5.2.6.1 HDD Management 16

5.2.6.2 Alarm Set 17

Email Alarm Notification 17

5.2.6.3 PTZ Setup 18

5.2.6.4 Mobile 19

Mobile Phone Access 19

5.2.6.5 Motion Detect 28

5.2.7 System Function 29

5.2.7.1 Time Set 29

5.2.7.2 Password 29

5.2.7.3 Video Setup 30

5.2.7.4 Language 30

5.2.7.5 Info....30
5.2.7.6 System Maintenance....30
5.3 Menu Lock....*31*
5.4 Video Search....*31*
5.5 PTZ Control....*31*
5.6 Record....*31*
5.7 Stop recording....*31*
Chapter 6: Net-Viewer Program....**32**
6.1 Plug-ins download and installation....*32*
6.2 Log-in to Net-Viewer....*32*
6.3 Main Interface of Net-viewer....*33*
6.3.1 Menu column....33
6.3.1.1 Live....33
6.3.1.2 Replay....33
6.3.1.3. Setup....34
① Record....34
② Alarm....34
③ PTZ Control....35
④ Network....35
⑤ Setting....35
⑥ Host Info....36
6.3.2 PTZ Control(Numbers 2, 3, 4 on Picture 6-3)....36
6.3.3 Live Play Control(Numbers 6 through 10 on Picture 6-3)....36
Chapter 7: Specification....**37**
Chapter 8: Windows Vista User....**37**
Chapter 9: Appendix....**39**
9.1 Operation Function Table....*39*
9.2 Recording Alarm setting....*40*
9.3 Troubleshooting....*40*
9.4 4 Channel System Connections....*41*
9.6 Accessory (Optional)....*42*

Safety Instruction

1. **Use proper power source.**

   Do not use this product with a power source that applies more than specified voltage (100-240V AC).

2. **Never insert anything metallic into the DVR case.**

   Putting something into the DVR case can be a source of dangerous electric shock.

3. **Do not operate in wet & dusty area or use near water.**

   Avoid places like a damp basement or dusty hallway.

4. **Do not expose this product to rain or use near water.**

   If this product accidentally gets wet, unplug it and contact an authorized dealer immediately.

5. **Keep product surfaces clean and dry.**

   To clean the outside case of the DVR, use a cloth lightly dampened with water (no solvents).

6. **Provide proper ventilation.**

   This DVR has a built in fan that properly ventilates the system.

7. **Do not attempt to remove the top cover.**

   If there are any unusual sounds or smells coming from the DVR, unplug it immediately and contact an authorized dealer or service center.

8. **Do not attempt to remove the top cover.**

   Warning: You may be subjected to severe electrical shock if you remove the cover of the DVR.

9. **Handle DVR box carefully.**

   If you accidentally drop your DVR on any hard surface, it may cause a malfunction. If the DVR doesn't work properly due to physical damage, contact an authorized dealer for repair or exchange.

10. **Use standard lithium cell battery. (NOTE: Manufacturer has preinstalled battery.)**

    The standard lithium cell 3v battery located on the mother board should be replaced if the time clock does not hold its time after the power is turned off. Warning: unplug the DVR before replacing battery or you may be subjected to severe electrical shock. Properly dispose of old batteries.

11. **Make sure there is good air circulation around the unit.**

    This DVR system uses a hard drive for video storage, which generates heat during operation. Do not block air holes (bottom, upper, sides and back) of the DVR that cool down the system while running. Install or place this product in an area where there is good air circulation.

.

Chapter 1: DVR Features

Real time monitoring	Supports real time surveillance via Monitor
Saves Recordings	DVR saves real-time recording image to HDD
Backup Recordings	Supports DVR backup via USB flash drive and hard drive.
Playback Recordings	4CH Supports DVR single CH and multiple CH playback of recorded files 8CH Supports DVR single CH playback of recorded files
Network operation	Supports remote surveillance by multiple users simultaneously
Alarm Setting	Supports HDD & video input alarm management
Mouse Operation	Supports Mouse operation for faster menu navigation.
PTZ Control	Supports PTZ camera operations through RS-485.

List 1-1

Other Features：

H. 264 video compression format： 4CH supports D1, HD1, and CIF resolution
8CH supports CIF resolution

ADPCM audio compression format

Windows Graphical interface

BNC and VGA video out ports

Supports remote live viewing via 3G mobile networks

Supports sending email alerts when motion is detected by system

Triplex (recording, playback and net transmitting at the same time)

Supports USB mouse, IR remote control operation

Rear USB2.0 ports for backup, upgrade and mouse operation.

Supports Double Encode bit network transmission

The video package time is adjustable

Multiple alarm record modes

Multiple languages OSD

Supports auto maintenance

Chapter 2: Layout

2.1 Front Panel

2.1.1 4-Channel Front Panel

1	◀◀:Rewind	10	Number 8	19	Number 5
2	▌▌:Pause	11	Number 9	20	Number 6
3	▶:Play	12	0: Mute Audio	21	▲: Up Arrow
4	▶▶:Fast Forward	13	ALL:Display All Cameras	22	◀: Left Arrow
5	■:Stop	14	Menu:Exit Menu	23	▼:Down Arrow
6	●:Record	15	:CH1	24	▶: Right Arrow
7	PWR: Power LED	16	:CH2	25	SEL: Select
8	HDD:HDD Lock	17	:CH3		
9	Number 7	18	:CH4		

List 2-1.1

2.1.2 8- Channel Front Panel



1	◀◀:Rewind	10	8 :CH8	19	5.: CH5
2	▌▌:Pause	11	Number 9	20	6.:CH6
3	▶:Play	12	0 : Mute Audio	21	▲: Up Arrow
4	▶▶:Fast Forward	13	ALL :Display All Cameras	22	◀: Left Arrow
5	■:Stop	14	Menu:Exit Menu	23	▼:Down Arrow
6	●:Record	15	1.:CH1	24	▶: Right Arrow
7	PWR: Power LED	16	2.CH2	25	SEL: Selec
8	7 :CH7	17	4.:CH4		
9	HDD:HDD Lock	18	3.:CH3	27	

List 2-1.2

2.2 Rear Panel

2.2.1 Channel Rear Panel

4CH

8CH

Item	Physical port	Connection method
1	Video input	Connect CH1-4 (BNC interface)
2	Video output	Connect monitor output (BNC interface)
3	Audio input	Connect signal input (RCA interface)
4	Audio output	Connect signal output (RCA interface)
5	Ethernet Port	Connect intranet, internet (RJ45 interface)
6	VGA Port(Optional)	Connect to VGA monitor
7	USB Port	Connect USB mouse
8	RS-485	RS485
9	Power Port	Connect power supply - DC12V 3A

2.3 Remote Control



1	**1-8**	Channel Select 1-8 ; Numeric key
2	**9、0**	Numeric Key
3	**ALL**	Preview all Channel
4	**Menu**	Enter/Exit Main Menu
5	▲	Up Key
6	▼	Down Key
7	◀ / ▶	Left / Right Key
8	**SEL**	Select Key/ Edit Key
9	◀◀	Rewind key
10	▶	Play Key, Enter to recording search menu
11	▶▶	Forward Key
12	●	Manual Recording
13	▌▌	Pause / Frame Play
14	■	Stop manual recording; Stop Playback
15	**Audio**	Undefined
16	**Mute**	Undefined

Mouse Operation

You can use a mouse instead of front panel buttons or remote control.

Click left key of Mouse	In menu lock mode, Enter into pop-up menu and clicking any sub menu to pop up Log-in window; on menu unlock mode, enter into pop-up menu, and then clicking left key to enter into any sub menu directly.
	After entering main menu, clicking left key could enter into any sub menu; On[Detailed file] menu mode, clicking left key could playback one recording file.
	Change the status of check box and motion detection area.
	Clicking combo box to access pull-down menu
	By clicking left key you can adjust Color control bar and volume control bar.
	By clicking left key you can select values in edit boxes or pull-down menu and supports Chinese word input, special symbol, numeric and character input, use instead of [Enter-] or [Backspace]
	In the [Detailed file] menu mode, clicking left key will playback one recording file.
Click right key of Mouse	In live display mode, clicking right key will display pop-up menu (shown as Picture 5-1).
	In Main menu or sub menu mode, clicking right key will exit current menu.
Double-click Left key of Mouse	In live display or playback mode, double-clicking left key will maximize the screen.
Moving Mouse	Select menu item
Sliding Mouse	On motion mode, sliding mouse will select motion area; On [Color set] menu mode, sliding mouse will adjust color control bar and volume control bar.

List 2-3

Chapter 3: DVR Installation

3.1 Hard Drive Installation

Caution： Please do not Install or take out hard drive when DVR is running!

First, loosen the screws in the left and right sides.



Secondly remove the cover



Third, connect data cord and power cable of main board to the according ports of DVR.



Next, Install HDD on the bracket fix then with screw, firmly secure the screw so that it can not get loose from such as vibration.



Next, check if the connectors are properly connected and there is no problem with wiring and close up cover and fix it with screws.



3.2 Camera and Monitor Connection

Connect camera cable to video input of DVR, and from video output of DVR to Monitor via BNC connector (Refer to section2.2-Rear Panel); or

If the camera is a PTZ speed dome, you could connect RS485 A & B to the according port of DVR respectively (refer to system figuration on Chapter 8).

3.3 Power Supply connection

Please only use the power adapter supplied with the DVR.

Chapter 4: DVR Boot up

4.1 System Initialization

Picture 4-1

After connecting the power adapter，the system will boot-up and start initializing.

4.2 Main Interface

Picture 4-2

z

After finishing system initialization, the system will enter into main interface. Picture 4-2 is the main interface displayed by system, which is showing no video input status. Once there are video inputs, the interface will display live images from the cameras. In main interface mode, if you use the mouse to double-click the live image of any channel, the image will be maximized to full screen, by double-clicking again, the display will be come back to display all cameras; clicking the right button of the mouse, will enter into Pop-up Menu; by clicking the left button of the mouse, you select menu items; when clicking any area outside the menu, you will exit the Pop-up menu.

Chapter 5: DVR Menu

Pop-up Menu

Picture 5-1

After finishing system initialization, click right key of mouse on main interface mode to enter into Pop-up Menu. Now you could carry out parameter setting and operate for Main Menu, Menu Lock, Video Search, PTZ, Start record, Stop Record and also operate for Start Cruise after successful PTZ parameter setting etc.

5.1 Main Menu Preview



5.2 Main Menu

Picture 5-2

After clicking right button of mouse, pop-up menu will be displayed on the screen. You can click [main menu] button on pop-up menu to enter into Main menu interface (Shown as Picture 5-2). You can also use the Menu button on the front panel to bring up the window, when using the front panel buttons use the FWD and REW button to move in the menu, and the SEL button to select the icon. You use the ESC button to return to previous window. In Main Menu mode, you can control device management settings, such as Camera, Recording, Network, Recording search, HDD, Alarm, PTZ Control, Mobile Phone & motion detection etc, you can also set system function settings, such as Time setting, User password, Audio/Video setting, Language select, and access system information, system maintenance etc.

5.2.1 Camera setup

Picture 5-3

Go to [Main Menu → Camera] to set up the name display and position display of each channel (Shown as Picture 5-3), You can also adjust image brightness, saturation, contrast and hue settings of each channel after entering into [Color] Menu and set up whether each channel can be previewed or not under Live display and/or Recording mode.

Please note that the name of each channel supports up to eight characters.

Picture 5-4

Below is the Color Menu where you can adjust image brightness, saturation, contrast and hue parameters of each channel.(shown as picture 5-4)

Explanation：

1、The modifications will be available after clicking [APPLY] button on the bottom of the sub-menu windows and being prompted to save and then clicking [ok] button.

2、If you want to cancel the modification, click [Exit] button to exit the menu.

3、When clicking [DEFAULT] button, all system default values will be reset to default value.

4、System default value indicates the value pre-set at the factory.

Picture 5-4A

Click [AUTOSEQ] button to start auto rotation function. (setting sub menu shown as Picture 5-4A. After starting auto rotation function, system will auto rotate the video images among CH1, CH2, CH3, CH4 and Quad (4CH) or CH1、CH2……CH8 and all CHS(8CH) in turn.

Default rotation time: 5 second

Settable time range: 0~10 second

Note: After apply "AUTOSEQ", you can exit the menu and click "▌▌ Pause" on front panel or remote control let it this function realize.

5.2.2 Record setup

Picture 5-5

Click [Main Menu] →[Record] to enter into [Record Setup] menu (Shown as Picture 5-5)

Functions：

1、The [Rec. Mode] button allows you to setup recording 24 hours, on motion, or on a set schedule.

2、[PACK time] indicates maximum continuous time length of recorded files (15, 30, 45, 60 min).

The [Record Setup] menu allows you set up recording status (on/off) of each channel, it also allows you setup recording image resolution and quality, and turn audio on/off. This menu also allows you select recording mode (recording after power on and scheduled recording) and recording file length.

Once a channel is set to “on”, the channel can record, if it is set to “off”, the video from the channel will not be recorded. **Resolution** options are D1, HD1 and CIF(4CH only); and **Quality** options are Best, Good and Normal.

When Audio is set to “On”, system will also record audio from the channels and will have audio output on playback mode; if it is set to “off”, you can not record audio and will have no audio output available on playback mode.

To record 24 hours a day, set the Rec Mode to Always. To record on motion or a set schedule, select Time Schedule Record and click the “Schedule” option, the Schedule interface will open as shown in (picture 5-6):



Picture 5-6

Recording options include All, CH-1, CH-2, CH-3, CH-4 or CH1 to CH8 respectively. Please click the channel you need, the channel you select will be highlighted in “Blue” unselected channels will be “Grey”.

To setup weekly schedules, click on the box of the recording status you want (Alarm, General, or No Record) and then click on each box in the schedule time line that you want this method to apply to. You can use the [From – To] pull-down menus and Copy button to copy settings from one day to another day or all days. After you complete the schedule you activate it by clicking the [Apply] button.

You can also click on the Default button to use the system defaults. The system default settings are:

Hr01:00 am-07:59 am : No recording

Hr08:00 am-18:59 pm : Normal recording

Hr19:00 pm- 00:59 pm : Alarm recording

Explanation: Under the recording Set menu and recording search menu, original color stands for no recording, “Red” stands for alarm recording, “Green” stands for normal recording and “Blue” stands for the channel and date you have selected.

5.2.3 Network Set

Enter into [Main Menu→Network Set] to proceed network set (Shown as picture 5-7):

Picture 5-7

After selecting network mode - such as DHCP、PPPOE and static allocation and setup web port, you could visit DVR remotely via network.

When selecting DHCP, DHCP server will allocate DVR IP address automatically.



Picture 5-8

When selecting PPPoE, you need to input user and password provided by ISP supplier and set up web port (details please refer to the below picture 5-8).



Picture 5-9

When selecting static allocation, you need to setup IP address, net-mask, gateway and web port (shown as picture 5-9).



Picture 5-10

If you apply for DDNS service and set up net parameter of DVR accordingly, you could visit DVR remotely via IE browser. (shown as picture 5-10)



Picture 5-11

If you need to visit DVR via Internet, you should setup the inflection of video port at the public Router located in the DVR (shown as Picture 5-11).

Host Port: 9000

Web Port: 8080

LAN IP address of DVR: 192.168.1.101

Input http:// router IP:8080 (192.168.1.101:8080) to you computer IE browser,then you will visit your DVR freely.

5.2.4 Recording Search

Click [Main menu→ search] to enter into [Video Search] menu (shown as the below picture 5-12).

Picture 5-12

Searched playback:

If you input specific date and click [Search], you will find all the recordings for that day. When you select [Date] item, you will playback the recordings in 4 channel mode (4 CH only); or, click [File list] button to display File list interface, where you can playback or backup the file you selected. See File List heading below.

You can play video Forward at 2x, 4x, and 8x speeds, Slow play at 1/2x, 1/4x, and 1/8x, normal play, pause and play frame by frame using the playback control bar, and adjust volume by clicking or sliding tune control bar. When playback has finished, system will return to previous menu.

File list

On the [Video search] menu mode, click [File list] menu to pop up the sub-menu shown below as Picture 5-21.This option will allow you to view all of the available files by channel and type (all, normal, or alarm). You can select a file and push the SEL button to playback the file, or use the FWD button and down button to select the option and backup the recording file you selected. You can also put a checkmark in the box at the end of multiple files if you want to backup more then one file.



Picture 5-13

First： Indicates the first page of recording history you have searched. When you view other pages, clicking [First] button brings you back to Page one.

PRE (Previous page): When viewing event list, clicking [Previous page] button will take you back to page before the one you are currently viewing (except the first page).

NEXT (Next page): When viewing event list, clicking [Next page] button will take you to the page after the one you are currently viewing (except the last page).

LAST (Last page): Indicates the last page of recording history you have searched. When you view other pages, clicking [Last page] button will take you to the Last page.

ALL (Select All): Allows you to select all the events on the current page.

INVERSE (Select Invert): Allows you to select other events on the current page except those you have currently selected.

Recording File Backup

If you want to backup one recording from the file list, you just select the recording and click [Backup] button. When the backup is completed you will be notified. Please click [OK] button to save your backup (shown as Picture 5-14).

Explanation: Backup file will be in H264 format, you can convert it to AVI format using the Multimedia Player program that comes with the DVR or through the net-viewer program, so you can use any player which supports AVI format.

Picture 5-14

Picture 5-15

5.2.5 Multi player

1、Copy backup file to your PC.

2、Open multimedia player and click [File→ Local (F)] to find/select the backup file, and then click [open] button

Note: the file type you have selected should be *.264 format.



Picture 5-16



Picture 5-17

3、Open backup file:



Picture 5-18

（1）、Click [Play] menu (P) on the top of multimedia player interface to select playing the backup file;

（2）、Click pop-up menu button on the bottom of multimedia player and [Play-] button, then the backup file will be played on the according channel.

（3）、The Menu brief on the bottom of multimedia player:



Date: 04/02/2009 recording date for the current backup file shown as right corner;

24H recording time: lie under [Date] menu. Black number button stands for current recording playback is normal recording for the time line.

0~60 Minute recording time quantum: Green part on play processing bar stand for recording length for one hour recording.

Recording date and time processing for the current recording file

1	Play	10	All the windows
2	Previous recording file	11	Add window
3	Pause	12	Start
4	Stop	13	Cut
5	Previous frame / Next frame	14	Delete
6	Slow play, Normal play, Fast Play	15	Convert AVI
7	Next Hour	16	OSD
8	Capture picture	17	Mute switch
9	Reduce window	18	Volume adjust

4、Please refer to the below [Video on] setting procedure (System default - video for every channel is on)



Picture 5-19

Setting→Video play setting →Normal video Bar→Select the channel you want to display→ Select ☑ to play the video→Apply→OK



Picture 5-20

5、Refer to the below for [Audio on] setting procedure. (Setting parameter will be available after re-starting multimedia player after [Audio on] set up.)

Setting→Audio channel setting → Normal video Bar→Select the channel you want to playback the

audio→Select ☑ the channel has audio files→Apply→OK.



Picture 5-21



Picture 5-22

After successfully setting the above, when you playback the current channel, you can open the channel's audio function at the same time as the video

5.2.6 Device Management

Picture 5-23

Options in device management include hard drive, Alarm, PTZ control, Mobile Phone Monitoring, and Motion Detection.

5.2.6.1 HDD Management

Picture 5-24

Click [Main Menu→Device → HDD] to enter [HDD Management] menu (shown as Picture 5-24)

Picture 5-25

When you install a HDD, the system will automatically detect if HDD is formatted or not; If HDD needs to be formatted, HDD status will be shown as "Not format", otherwise, the HDD status will be shown as "Normal" (refer to Picture 5-25)

TOTAL SPACE: Indicates total space available on Hard Drive.

FREE SPACE: Indicates unused space available on the Hard Drive.

USEABLE REC TIME: Based on current image detail/quality and frame rate, system will show you how Recording time you have left on the Hard Drive.

OVERWRITE: If you select "on" the system will automatically overwrite the oldest recordings once the hard drive is full; if you select "off", recording will stop once the hard drive is full.

HDD FORMAT: You use this option to format the hard drive, you can not record files to the hard drive until it has been formatted. Click [Format HDD] button to start formatting. When selecting [Format HDD] option the system will prompt you – "Format HDD will loss all the data, do you confirm?" ; click "OK", system will prompt you **–** "Is formatting…" and "successful format"; and then system will restart automatically.

USB FORMAT: Use this option to format USB devices.

5.2.6.2 Alarm Set

Picture 5-32

Click [Main Menu→Device → Alarm] to enter into [Alarm setup] menu to setup Alarm warnings (shown as Picture 5-32).

HDD LOSS: Options are "On" and "Off". If you select On there will be a buzzer sound and "H" sign on screen when HDD is not detected or not formatted; on the contrary, if you close the function, there is only "H" sign to indicate HDD not found, but no alarm sound when HDD not found or not formatted.

HDD SPACE: Options are "On" and "Off". When the alarm function is on, there are alarm sounds when the HDD is running out of space; when the function is off, there are no alarm sounds.

VIDEO LOSS: Options are "On" and "Off". When the function is on, system will issue alarm sound and display video loss on the preview interface; when the function is off, system will have no alarm sound, but the preview interface will display video loss.

Alarm Type	Function
Video Loss	Sends alarm when DVR can't receive video signal (such as camera damage, cable broken or damaged or power supply malfunction).
Motion Detection	When an object moves into motion detection area, alarm will be triggered. You can adjust sensitivity level to suit the needs of your actual application environment.
HDD loss	When Hard Drive is not detected (HDD damage, power supply malfunction), or HDD auto-overwrite is off, and free space is not enough, an alarm will be triggered.

List 5-1

Email Alarm Notification

(to send notice to email account when motion alarm is triggered)

Picture 5-27

Click the [Email setup] menu to enter into its sub menu (shown as Picture 5-27).

Picture 5-28

On the [Email setup] mode, refer to its parameter setup shown as picture 5-28 when setting email alarm to "on".

SSL: is a security link transport protocol. You can encrypt your communication info (including your email) using SSL to prevent hackers from monitoring your email or communication info and even your password.

Please set SSL to "On" via Gmail.com server, and set to "Off" via other mail server.

If your setting is still not right, please contact the web site where you have applied for your email box to get SMTP server and SSL of mail box.

Picture 5-29

SMTP Port: indicates sender port of SMTP server. Generally the SMTP port value is 25, but there are exceptions, for example, SMTP port of G-mail server should be 465.

SMTP server: indicates server address you use.

Sender email: indicates sender's email address. The email address should be consistent with the server you use. That is to say, when you use email address – aaa@gmail.com, the according server should be smtp.gmail.com.

Receiver address: indicates receiver's email address. The email address is used to receive image transmitted from motion detection alarm of DVR. Please clear the images you have received as soon as possible to avoid overloading your email account. For detailed SMTP protocols settings refer to the below picture 5-30.



Picture 5-30

5.2.6.3 PTZ Setup

Picture 5-31

Enter into [Main menu→Device→ PTZ Setup] to select the channel you want to control and set PTZ protocol (Pelco-D or Pelco-P), Baud Rate (1200, 2400, 4800, 9600), Stop bit (1, 2), Parity Check (None, Odd, Even Mark Space), Address Code and Cruise status respectively. Please note the above mentioned channel settings must match the settings of the PTZ camera.

5.2.6.4 Mobile

Picture 5-32

Click [Main menu→Device→Mobile] to enter into [Mobile] menu.

User Name: indicate user name of DVR.

User password: indicate user password of DVR

Server port: Mobile monitoring port. Setting range is between 1024 and 65535. Please note that

Explanation: Please connect DVR to Internet before setting DVR port number and the server port no is not equal to network menus.

Mobile Phone Access

The DVR is currently compatible with mobile phones running Windows Mobile and Symbian operating systems on 3G networks.

Before you can access the DVR from a mobile phone you need to setup the Network Configuration on the DVR. Go to section 5.2.3 Network Setup on page 14 of the product manual for instructions on how to do this. You also need to go to the Main Menu then Devices then Mobile and enter your user name and password, and set the Server Port to 18600. This port also needs to be forwarded to the IP address of the DVR along with the ports from 5.2.3 Network Setup.

Explanation: You can only see one channel at a time when viewing from a mobile phone. The speed of the display depends on the speed of the internet connection.

When accessing from a mobile phone with Windows Mobile operating system, use the following procedure:

1. Webcam installation

First you need to install the webcam program that is included on the CD that comes with the DVR by copying the “QQeye.CAB” file to the mobile phone. You can do this by attaching the mobile phone to a computer and copying the file from the CD to the memory card on the phone, or by copying the file from the computer to the phone’s memory card through a memory card reader or through a Bluetooth connection.



Pic 1



Pic 2



Pic 3

2. Click the windows mobile folder (red box in Pic 1) and choose the file QQeye” Select the file which will open the window in Pic 3. The file is generally faulted to save as Device, direct to phone, (shown in Pic 3) but you can save it to Device or Storage Card.

3. Choose storage location and click [Install] button (red box in Pic 3) to start the installation (please refer to display in Pic 4 below)



Pic 4



Pic 5



Pic 6

4. After installation finishes, click the icon named QQeye (red box in Pic 5) to run the program. This will display the program screen in Pic 6.

5. Settings: Click [Setting] button (red box in Pic 6) to enter the Setting menu shown as Pic 7



Pic 7



Pic 8

Pic 9

User name: same as user name setup in DVR under Menu, Devices, Mobile

Password: same as password setup in DVR under Menu, Devices, Mobile

Server address: Public IP address of router DVR is connected to.

Web port: Same as the Server Port you setup in the DVR, it needs to be forwarded to the IP address of the DVR, setting range is between 1024 and 65535, the default setting is 18600. Note: this port is in addition to the ports used for standard remote access.

Channel: Select the channel from the DVR you want to monitor and click [OK] button (red box in Pic 7) to display the screen in Pic 8 and start video connection.

6. Main interface operation (Pic 8)

Click [Disconnect] button to stop displaying live image of the channel.

Click [Setting] button to modify the settings.

7. Video connection Display

Normal Mode:

You will find network connection status info under the video image:

Display on the left corner: Network transmission speed, Frame rate and Resolution.

Display on right corner: percentage of buffer display, Connection success,Connection fail, Play and Stop.

Function of Buttons under the video image from left to right: PTZ control (Left, Right, Up and Down), area select (Zoom out and Zoom in), Focus (Add “+” and deduct “-”) and Iris (Add “+” and deduct “-”) and Snap to capture screen image.

8. Display mode: You can convert normal display into full-screen display by clicking the screen on the mobile phone (displayed as Pic 9)

When accessing from a mobile phone with Symbian operating system, use the following procedure:

1. First you need to copy the file with suffix “QQeye.CAB” that is included on the CD disk to the mobile phone.

Copying file is save to storage card by default, and the file can also be transmitted from the CD through a computer by Bluetooth technology to save to Inbox (Pic 1). Select the QQEye program (red box in Pic 1) which will display Pic 2.

2. Select the QQEye icon in this window (red box in Pic 2) to install it, this will display Pic 3).



Pic 1



Pic 2



Pic 3

After the phone finishes preparation it will display Pic 4 asking for permission to install the program. Select the Yes button (red box in Pic 4). This will display the window in Pic 5.

``



Pic 4



Pic 5



Pic 6

3. Click the Continue button (red box in Pic 5) on the information box displaying the program and current version. This will display the window in Pic 6.

4. Next choose where you want to install the program, to phone memory or to the memory card, and click on the Select option (red box in Pic 6). This will display the window in Pic 7, click on Continue (red box in Pic 7) which will display the screen in Pic 8 and tell you it is installing the program (red box in Pic 8).



Pic 7



Pic 8



Pic 9

5. Once the installation is complete the window in Pic 9 will be displayed to tell you that installation is completed. Then you can go to the Applications folder and select the QQEye program (white box in Pic 10) and click on the Open option (red box in Pic 10) to display the settings menu. After you complete the settings and click on the Done button (red box in Pic 11) the Video window in Pic 12 will be displayed.



Pic 10



Pic 11



Pic 12

Default Access Point:

Input the access point. System default for the access point is GPRS connection.

Server Address:

Input the public IP address of the router the DVR is attached to (refer to section 5.2.3 Network Setup on page 14 of the product manual).

Server Port:

Web port: Same as the web port setting on the DVR, you need to forward this port from the Router to the DVR. Setting range is between 1024 and 65535, the default setting is 18600. Note: this port is in addition to the ports used for standard remote access.

User Name:

Same as user name setup in DVR under Menu, Devices, Mobile

Password:

Same as password setup on DVR. (Please press Function key to save the password, left soft key won't be able to save the password)

Channel:

Select the channel you want to monitor and click [OK] button to start video connection

Network connection status: percentage of buffer display, connection success, connection fail, play and stop.

Channel select, PTZ control, Zoom in/out, Focus and Iris

Play/Stop, Full screen/ Normal Display, Capture, Parameter setting and Exit【】

By clicking on the image you can see it full screen as in Pic 13


Pic 13

Step 1: Download iTunes

Visit Apple website http://www.apple.com/itunes/ to download & install the **iTunes**.

Step 2: Download & install surveillance software "Aplayer"

2.1 Register iTunes Store

2.1.1 Run the installed iTunes, you might need to create an account to visit iTunes store firstly. Move to the menu "Store", and click the option "Create Account".



2.1.2 Continue


With an iTunes Store Account, you can download the latest music, videos, and more.
To begin creating your iTunes Store Account, click Continue.
Cancel
Continue

2.1.3 Select & continue


om, Inc., used under license. 1-Click is a convenient feature that allows you to
Store with a single click of your mouse or other input device. When accessing
asing or renting (as applicable) may be activated for all your transactions by
" check box in the "Are you sure you want to buy and download ... ?" dialog box
u may reset this selection at any time by clicking "Reset Warnings" in your
your iPod or iPhone, 1-Click is activated for each transaction by pressing the
I have read and agree to the iTunes Terms and Conditions.
Printable Version
Cancel
Continue

2.1.4 Fill in your personal info & continue.



Please note that the options of Payment Method are different from different regions, please select another payment method. Don't worry, "Aplayer" is a free software & you don't need to pay for it.

2.1.5 Finished the register, and go to your email box to verify your account.


Secure Connection
Verify Your Account
An email has been sent to the address below with a link to verify your account. Make sure to check your email and follow the link to complete your account sign up.
aplayerid@gmail.com
Resend the email or change your email address
Done

Click the link included in the email message.


Dear Yourname Yourname,
Your iTunes Store Account has been set up, with the following Apple ID:
aplayerid@gmail.com
Please click the link below to verify your account, then sign in to the iTunes Store using your new Apple ID and the password you created when you set up your account.
https://buy.itunes.apple.com/WebObjects/MZFinance.woa/wa/verifyAccountEmail?evcode=VT6KXL6PMRXX4
Sincerely,
The iTunes Store Team
Apple Inc.

It will connect to the iTunes store and turn to iTunes interface.


One Moment Please.
Connecting to the iTunes Store.
Loading.
If iTunes doesn't open, click the iTunes application icon in your Dock or Windows Task Bar.

Sign in your account.

The register of your iTunes store account has been done.


Congratulations
Your iTunes Store Account has been successfully created.
You can now shop for your favorite music, movies, TV shows, and more.
If you're new to iTunes or the iTunes Store, check out our free video tutorials:
Shop the iTunes Store
Buy Movies and TV Shows
Get Free Podcasts
Explore the Jukebox
Import Music from CDs
Create Playlists
Sync to Your iPod
View Free iTunes Tutorials
Done

2.2 Authorize Computer

You need to authorize your computer with the registered ID.

Move to the menu “Store”, and click the option “Authorize Computer”.



Input your registered ID & password, then click Authorize button.

Authorize Computer
Enter Account Name and Password
If you have an Apple Account (from the iTunes Store or MobileMe, for example), enter your Apple ID and password. Otherwise, if you are an AOL member, enter your AOL screen name and password. You may authorize up to 5 computers for each account.
Apple ID:
aplayerid@gmail.com
Example: steve@me.com
Password:
Forgot Password?
AOL
Authorize
Cancel

2.3 Download & install "Aplayer" into your iPhone

2.3.1 Click iTunes Store(1), then input "aplayer" into the search bar(2) on the right upper corner and press Enter.



You will find the Aplayer icon displayed as below.

2.3.2 Click the icon and it will turn to the download page. Click the "GET APP" button to download the file.

You will find the downloaded file on the directory of Application

2.3.3 Connect your iPhone to the computer, you will find your Device displayed on the left sidebar. Select the DEVICES ID(1), and then click "Applications" option(2). Select the "Sync Applications" & "Aplayer" (3) and then click "Sync" button(4).



*** The devices ID is different from different iPhones.**

After finishing the sync, you will find the Aplayer Icon on your iPhone.(Picture I-01)



Picture I-01



Picture I-02

Step 3: Setup & run "Aplayer"

Main interface of Aplayer & function keys: (Picture I-02)

Ⅰ. Direction keys of PTZ control

Ⅱ. Zoom+ & Zoom-

Ⅲ. Focus+ & Focus-

Ⅳ. Iris+ & Iris-
Ⅴ. Channel selection keys
Ⅵ. Play & Pause
Ⅶ. Snapshot
Ⅷ. Full screen
Ⅸ. Next group of channels
Ⅹ. Setup

3.1 Access information setup

Turn into setup menu, and fill in the information according to your DVR Mobile settings.

Server IP: input the IP address or domain name to visit your DVR
Port: same with the server port you have set in your DVR mobile settings
User ID: same with the user name you have set in your DVR mobile settings
Password: same with user password you have set in your DVR mobile settings
After finishing the settings, press “Back” button to the main interface.

Press Play button to start mobile surveillance.
Press channel selection keys to switch camera picture.

5.2.6.5 Motion Detect

Picture 5-33

Click [Main→Device→Motion] to enter into the [Motion Detection] menu to setup motion detection recording.

The [Motion detection] Menu has three sections, including Channel Status, Sensitivity and Motion area.

Channel STATUS: This option allow you enable motion detection on any channel.

SENSITIVITY: This option allows you to set sensitivity level of motion detection from 1 to 4 with 4 being the most sensitive.



Picture 5-34

MD AREA: This option allows you select the area you want to be sensitive to motion. The channel is separated into a 13*10 area. When any object moves into the motion detection area, and the area where the object is located is displayed in red recording will be triggered. In the semi-transparent area the motion detection is off.

5.2.7 System Function

Picture 5-35

The [System] Menu includes the below sub-menus: Time Set, User Password, Audio/Video Setting, Language select, System Info and System Maintenance.

After entering into the [System], you can configure the system to meet your needs.

.

5.2.7.1 Time Set

Picture 5-36

Click the [Main menu→System→Date/Time] in turn to enter into [Time Set] menu. You could not only modify system date, time and format, but also set daylight saving time and mode.

5.2.7.2 Password

Picture 5-37

This option allows you set the device ID for the DVR and set the system password if you want to use one. The new passwords will be available after clicking [APPLY] button.

.

Picture 5-38

When you set Password Enabled to “ON” (shown as Picture 5-38), you can setup a user password and administrator password respectively. The password supports up to 6 characters.

5.2.7.3 Video Setup



Picture 5-39

Click [Main Menu→System→VIDEO] to setup Video, here you can set Camera system（PAL, NTSC）In the USA we use NTSC(Optional).

You can also set the resolution for the VGA video out port. Your options are 800x600, or 1024x768, or 1280x1024.

5.2.7.4 Language



Picture 5-40

Enter into [System Language] menu to select the language you want to use on the DVR (shown as Picture 5-40) and click [APPLY] button. The selection will be available after system Auto restarts. and this is available only when the DVR comes with Multiple language OSD.

5.2.7.5 Info.



Picture 5-41

Click [Main Menu→ System→Info] to enter into [System Information] menu to view system info, including Device type, Software (firmware) version and MAC address etc.

5.2.7.6 System Maintenance

Picture 5-42

This option allows you reset the DVR to factory default settings, update system software (firmware), and set system auto-maintenance. Click [Main menu→System→Maintain] to enter into the [System Maintain] menu (shown as Picture 5-42).

When opening auto-maintain function, you can setup system to restart regularly.

5.3 Menu Lock



Picture 5-43

As a system safety feature you can click [Menu Lock] menu to lock menu when leaving the DVR. If you want to login to the DVR, you would input device code and password (refer to the Menu Locking interface- Picture 5-43).

Explanation: User only has the authority to search recordings, but Administrator has full authority over Main Menu operations

5.4 Video Search

Click pop-up menu video search to enter into [Video Search] menu you search files and playback recordings. For more information on this operation refer to the previous section 5.24.

5.5 PTZ Control

Picture 5-49

We introduced setting PTZ parameters previously in chapter 5.2.5.3. Here we will discuss how to operate PTZ controls.

Click pop-up menu to show PTZ option and enter into PTZ control interface (shown as Picture 5-49). You can now click Z+&Z- keys to zoom In or out, click F+&F- keys to control camera focus and click I+&I- to adjust iris.

Cruise Set

Open auto cruise function on PTZ setting menu if you want to setup cruise function (system default: on), and set up cruise channel, cur point and total quantity and stop time etc.

Channel select: select the channel with the PTZ camera
Total: set up presetting bit quantity
Cur Point: System has default starting (current) cruise point as 01. You can use this option to set additional cruise points.
Stop time: sets the pause time at each stop.
GOTO：select this option to go to specific preset points

Set: save the preset point. After setting channel and setting the position by adjusting PTZ direction key you click [Set] button to setup the pre-set point. Please note you will click the [Save] button to finish the setting successfully. If you want to combine Zoom, Iris, Focus and direction keys into the pre-set setting, please return to previous menu (shown as Picture 5-56) to add additional settings, and then enter into Cruise Set again and click [Set] and [Save] to make sure your setting is setup successfully.

Clean: remove settings.

Note: this DVR model supports up to 100 pre-set points. But actual quantities may be restricted by the PTZ camera you are using.

5.6 Record

When you want the system to start recording click [Rec] button to start manual recording.

5.7 Stop recording

If you want to stop manual recording click [Stop Record.] menu or [Stop] button

Chapter 6: Net-Viewer Program

6.1 Plug-ins download and installation

Open IE browser and input IP address and web port of DVR, such as http://172.18.6.202:80/ and confirm to download and install webcam. If your computer is connected to internet, computer will auto download and install the webcam.

Reminder: If the webcam is not downloaded successfully, please check if your browser's safety level or firewall setting is too advanced. Also refer to section 5.2.3 Network Setup to make sure network configuration is correct, ports are forwarded correctly, and ActiveX is enabled.

6.2 Log-in to Net-Viewer



Picture 6-1

After webcam installs plug-ins, please select log-in language (Chinese or English) and enter password and click [Log-in] button, and now you can view DVR remotely through Net-Viewer.

Please note default password is empty. System allows Administrator to set new password as per instructions in section 5.2.6.2 - [Password set] menu. **Note: If you want to delete old IE webcam at DVR system update, run the command characters: "regsvr32/u dvrocx.ocx"**

Picture 6-2

After successful Log-in to Net-viewer, system will enter into live display interface and connect to audio/video feed automatically (shown as Picture 6-2).

6.3 Main Interface of Net-viewer

Picture 6-3

Log in Net-viewer and show the interface as follows

6.3.1 Menu column (Section 1 on Picture 6-3)

6.3.2 PTZ Control (Numbers 2, 3, 4 on Picture 6-3)

6.3.3 Live Play Control (Numbers 6 through 10 on Picture 6-3)

6.3.1 Menu column (Section 1 on Picture 6-3)

Menu column include [Live] menu, [Replay] menu and [Setup] menu and [Logout] menu.

6.3.1.1 Live

After Logging-in to system, system will enter into Live display (shown as Picture 6-3).

6.3.1.2 Replay



Picture 6-4

This option allows you to playback recordings remotely.

First select the day, channel and type and proceed searching and refreshing; second select any event from search result list to playback.

Please note you can control playing speed by sliding the playing-control bar on the bottom of the interface (shown as Picture 6-4).

Play button: [Play]/[Pause]

Stop button: stop playing record

F.F. button: fast forward playback recording
Slow button: slow playback recording.
Next Frame: play frame by frame.
264 TO AVI button: convert file from H.264 format to AVI format

The native format of the backup files is H.264, you can convert H.264 format into more familiar AVI format by clicking the key of 264 to AVI.

6.3.1.3. Setup

Click [Setup] menu to enter into its sub menu, including [Recording Mode] menu, [Alarm Mode] menu, [PTZ Control] Menu, [Network Setting] menu, [System Setting] menu and [Host Info] menu.

Explanation: Only when DVR is on the status of live display, you could modify and save its parameters remotely at this moment, the settings are available. The modification method to DVR via Net-viewer is the same as local adjustment of DVR.

① Record

Picture 6-5

Enter into sub menu – [Recording Mode] menu, you can select on/off for every channel, and adjust recording parameters (resolution, quality, audio, REC mode and Schedule) remotely via Net-viewer.



Picture 6-6

Click the [Schedule] menu to enter into its sub menu (shown as Picture 6-6).

Remote setup methods are the same as local DVR setup. Please refer to Section 5.2.2 Record Setup

② Alarm

Picture 6-7

Click [Alarm] menu to enter into its sub menu (shown as Picture 6-7).

You can set motion detection alarm, motion recording, motion trace, motion sensitivity, video loss alarm, HDD not enough space alarm, HDD not found alarm and alarm output time etc.

For details on setup method please refer to section 5.2.5.2.



System allows you setup motion detection settings for each channel of DVR remotely (shown as Picture 6-8)

Picture 6-8

③ PTZ Control

Click [PTZ control] to setup PTZ cameras. Remote setup methods are the same as local DVR setup.

Please refer to Section 5.2.5.3 (shown as Picture 6-9).

Picture 6-9

④ Network

Click [Network] to enter into [Network] menu. Remote setup methods are the same as local DVR setup.

Please refer to Section 5.2.3. – Network Set.

Picture 6-10

⑤ Setting

Click [setting] menu to enter into the menu interface (shown as Picture 6-11);

Click […] button to preview net-viewer recording saving path and screen capture saving path.

The menu also allows you to set a lower bandwidth for Internet video transmission, set user password, turn daylight saving time on/off, etc.

Picture 6-11

⑥ Host Info



Picture 6-12

Click [Host Info.] to enter into the sub menu (shown as Picture 6-12). Here you can check Usage rate of HDD, available recording time, software version and MAC address.

6.3.2 PTZ Control(Numbers 2, 3, 4 on Picture 6-3)

②.PTZ control: indicates focus, zoom and iris control of PTZ
③.Setting: this option allows you to setup PTZ parameters.
④.Invoke: Invoke PTZ settings
⑤.Clear：clears current PTZ parameters.

6.3.3 Live Play Control(Numbers 6 through 10 on Picture 6-3)

⑥ On / Off Live display [ ]：When Live display status is “On”, Clicking the button closes Live display. When “Off” clicking the button opens the Live display.

⑦.Capture [ ]：Capture Screen image and save to PC as *bmp image.

⑧.Recording [ ]：Operate DVR recording remotely

⑨Channel display [ ]：The icons stand for Single Channel display, Quad Channel display, 3x3 Channel display and 4x4 Channel display respectively.

⑩.Volume control [ ] Click or slide the control bar to adjust sound volume.

Chapter 7: Specification

Model	4CH	8CH
Video System	NTSC / PAL(Optional)	
Compression Format	Video：H.264 / Audio：8kHz*16bit ADPCM	
Video Output	4-CH BNC Input/ 2-CH BNC Output / 1-VGA output (Optional)	8-CH BNC input/2-CH BNC output / 1-VGA output (Optional)
Audio I/O	1-CH RCA audio input/ 1-CH RCA audio output	
Display Resolution	D1：704×576(PAL)　704×480 (NTSC)	
Frame rate	Single CH　PAL：25 fps ，NTSC：30 fps	
Recording Resolution	PAL: CIF(352*288), HD1(704*288) D1 (704*576） NTSC:CIF(352*240),HD1(704*240) D1 (704*480)	PAL：CIF(352×288) NTSC：CIF(352×240)
Recording Frame Rate (shared)	PAL：25 fps@D1, 50 fps@HD1, 100 fps@CIF NTSC：30 fps@D1, 60 fps@HD1,120 fps@CIF)	PAL：200 fps@CIF NTSC：240 fps@CIF
HDD	1 SATA HDD, up to 1024GB；USB removable HDD	
Video Mode	Always / schedule / manual /motion detection	
Record Pack Time	15/30/45/60min	
Video backup	USB flash disk / removable HDD，USB Burner, Network backup to AVI File Format	
Playback Mode	PLAY /SLOW /FWD/Frame by Frame	
Alarm Type	Motion/Video loss/HDD Space/HDD Loss	
PTZ Control	Built-in RS-485 port, supports PELCO-P & PELCO-D	
USB 2.0 Port	Supports USB mouse，removable HDD，USB flash drive to backup to AVI file and upgrade system	
Ethernet	One RJ-45 10M/100M self-adaptable Ethernet interface	
Network Protocol	Supports TCP/IP, DHCP, UDP, DDNS, PPPOE network Protocol	
Network Function	Support preview live display remotely via mobile phone and real time monitoring via IE-based browser and/or network, and support parameter setting of DVR remotely.	
Power consumption	10～15W (exclude HDD)	
Power Adapter	DC 12V / 3A	DC 12V / 3A
Working Temperature	50°F to 104°F (10℃ to 40℃)	
Working humidity	10%～90%	
Dimension (W x D x H)	11.75 x 9 x 2 in (300 × 220 × 47 mm)	

List 7-1

Chapter 8: Windows Vista User

1、Open IE browse firstly, then enter into Tool bar-



and select



to appear the below picture:



2、Second, select 

icon and tick the settings of “ActiveX controls and plug-ins”to Enable, details as follows:



3.



4.



Lastly after tick all the “Enable”, please click 

to exit. At this moment, you could input IP address to run your programme.

Open IE browser and input IP address and web port of DVR…computer will auto downloadand install the widget.

We suggest Visita user set user access authority in order to make your PC safer. Setting processing as follows:

Click [Start→Set→Control panel→User account] to set user access authority shown as below picture.

User Accounts
Turn User Account Control On or Off
Search
Turn on User Account Control (UAC) to make your computer more secure
User Account Control (UAC) can help prevent unauthorized changes to your computer. We recommend that you leave UAC turned on to help protect your computer.
Use User Account Control (UAC) to help protect your computer
OK
Cancel

Remind: If the widgets are not downloaded successfully, please check if your browser's safety level or firewall setting is too advanced.

Open IE browser to enter into [tool→ Internet Option→Internet user-defined level→enable widgets.

Downloading and auto running install widgets need one minute, please wait…patiently.

Chapter 9: Appendix

9.1 Operation Function Table

Type	Title	Description	Page
Principle Setting	Time setting	Setting system date, time and format and day-light saving time setting	21
	Language Select	Setting system language	22
	CH Setting	Setting CH title and position; adjusting image color parameter value; setting CH display to ON / Off and time display/recording time overlaying to On/Off.	11
	Rec. Setting	Setting image quality, resolution, volume, recording mode an pack time	12
	Rec. Search	Time based search, channel based search and rec. mode based search.	14
	Rec. Playback	Specified time playback, scheduled playback, file list playback	14
	Playback mode	Play, play frame by frame, multi-speed forward and multi-speed rewind	14
	File backup	U flash disk and removable HDD backup, DVD recorder backup and network download backup	15
	HDD Manage	Check HDD status, usage space, setting HDD auto-overwrite	16
	VID/AUD Setting	Adjust VGA resolution, select system and volume control	22
Advanced Setting	User password	Setting or modifying user password	21
	Alarm setting	Setting HDD lost, HDD space, video loss, alarm management and Email alarm	26
	Motion detection	Setting on/off status of MD; select sensitivity and setting motion detection area.	20
	PTZ control	Selecting CH and setting PTZ protocol, baud rate and PTZ address for the CH	27
	MP Monitor	Setting user name, password and server port.	
	System Maintenance	Setting system auto maintenance, maintenance time regularly, system upgrade, ex-factory default value recovery and manual restart system	22
Network Setting	Network and Port setting	Selecting network mode and setting net-viewer port, web port, DNS and DDNS parameters.	27
Network Function	Live display	Real time video input remotely	25
	Remote recording	Setting recording mode and status of DVR remotely	28
	Remote playback	Check local recording history via network	25
	PTZ control	Remotely control PTZ camera, position, focus, zoom and iris etc.	28
	parameter set of DVR remotely	Setting local CH display, recording, alarm, PTZ control parameter value via network	26
	Network download	Backup recording file via network	25
Auxiliary function	System info	Check device model, software version and MAC address	28
	（）	In addition to illustrating picture, Parenthesis generally indicate optional parameter value of previous menu.	
Menu button	Confirm	The button allows you save the modification of parameter value.	
	Recover default	The button allows you recover default value of current menu or system	
	Exit	The button allows you exit the current menu.	
	Next	On multi-channel mode, the button allows you check or modify other channel's parameter; on [File list] mode, the button allows you display next page.	

List 8-1

9.2 Recording Alarm setting

Please refer the below matrix: "⊥" stand for "only alarm but no recording"; "AMR" stand for "alarm recording"; "NLR" stand for "normal recording"; and "NOR" stand for " no recording". Once alarm is triggered, alarm icon will occur, and when many alarms are triggered, alarm remarks will occur on the screen.

Recording alarm setting		Alarm icon	Recording Mode				
			Recording after power on	Timing recording			Manuel Recording
				AMR	NLR	NOR	
Alarm mode	MD alarm	M	AMR	AMR	NLR	⊥	NLR
	HDD loss, HDD space full	H	⊥	⊥	⊥	⊥	⊥
	Video Loss	Video Loss	⊥	⊥	⊥	⊥	⊥

List 8-2

When DVR is in recording mode, [R] icon or [M] icon will appear on the screen. But when there are [I] icon and [M] icons on the screen it indicates a motion alarm was triggered. When [H] icon appears on the screen, that mean a hard drive alarm has occurred.

9.3 Troubleshooting

1. Q: What can I do if the system does not detect the HDD?

A: Check the data and power cables and make sure they are securely connected.

2. Q: We have changed the password but do not remember the new password, how can we access the system?

A: If you forget system password, enter 0800808 into the password field to reset the password

3. Q: We are not getting any video signal on the DVR, what is wrong?

A: Check to make sure the cables are securely connected to the BNC ports on the DVR. You can also try another cable to make sure there is not a problem with the cable. Make sure you have selected the correct video format for your country (NTSC or PAL), is the USA we use NTSC.

4. Q: Can the DVR have problems if it gets too hot, how can I prevent this?

A: The DVR has a fan to help it dissipate heat while it is working. Please place the DVR in a place where there is good air circulation and away from high temperatures to increase stability and life of the DVR.

5. Q: My remote control does not work when the DVR is in Live mode but the front panel buttons are working, what is wrong?

A: Make sure nothing is blocking the LED on the remote, or the receiver on the DVR, if both are ok, check the batteries.

6. Q: Can I use the hard drive from my PC in the DVR?

A: You can if the hard drive is the same type and the size is supported by the DVR. If you install it in the DVR it will be formatted for use in the DVR and the PC will not be able to read it.

7. Q: Do I have to stop recording to playback files on the DVR?

A: No you do not have to stop recording, the DVR will support both functions at the same time.

8. Q: Can I erase files from the hard drive of the DVR?

A: You can not erase individual files, you would need to format the hard drive which will erase all of the files

9.Q: Why can't I log-in to the Net-viewer program?

A: Please verify that the Net mode is correct, The cable to the RJ-45 port is well connected to the DVR and the router, and that you are using the correct password.

10. Q: We have attached a PTZ camera but can not control it, what is wrong?

A: Verify that the Protocol, baud rate, address, and other settings on the PTZ camera match the settings you have put into the DVR. Make sure the data cables are attached firmly to the RS485 port on the DVR.

11. Q: Why does the Buzzer keep sounding?

A: Please check to see if motion detection is on and the system has detected motion, make sure the hard drive is being detected and has sufficient space available, and that none of your cameras have lost video. You can turn off the buzzer in the Alarm setup option.

9.4 4 Channel System Connections

(Diagram is for reference only to show where to attach various devices to the DVR, the cameras, USB flash drives, monitors and computers are not included with the standard DVR package)

4-CH.



8-CH.

9.6 Accessory (Optional)

Power Cord

Power Adaptor

User Manual

USB Mouse

Software CD

Remote Controller

The material in this document is the intellectual property of our department .

No part of this manual may be reproduced, copied, translated, transmitted, or published in any form or by any means without our department prior written permission.

Our products are under continual improvement and we reserve the right to make changes without notice. But no guarantee is given as to the correctness of its contents.

We do not undertake any responsibility for the harms cause by using our product.

The model of the products in the user's manual only for recognition, but these names also perhaps are belong to other company's registered trademark or the copyright.

The product picture may differ from the actual product, only for your reference. The accessories will probably be different according to the different selling areas. For details of accessories, please refer to your local distributor.

Copyright reserved